



1-51, 2-52

1-56, 1-60, 2-51, 2-59, 2-71

Низ / Bottom / Alapuoli




- RU** Инструкция по сборке
- EN** Assembly instruction
- FI** Koontaohje




1027
28



1038
26



1006
36




1004
32




1028
28




1040
12



1053
4




1072
6




1070
3






1010
4




1042
3









3




4



5



6



7

