

АЙНО


Стеллаж №2, №4, №5



RU Инструкция по сборке

EN Assembly instruction

FI Koontaohje




1006
20



1008
4



1004
12



1096
22




1097
22




1038
50



1074
2



1098
2



1048
1

