



Тумба ТВ 160 Пенни






















Прежде чем приступить к сборке, ознакомьтесь с памяткой на обороте





- | | | | |
|-----------|------------------------------------|-----------|--------------------------------|
| D | Montageanleitung | GB | Assembly instructions |
| FR | Notice de montage | IT | Istruzioni di montaggio |
| NL | Handlieding voor de montage | PL | Instrukcja montażu |
| CZ | Montážní návod | SK | Návod na montáž |
| HU | Szerelési útmutató | RO | Instrukțiuni de montaj |
| TR | Montaj talimatı | RU | Инструкция по монтажу |










No	Size/MaB (mm)	Qty	✓	No	Size/MaB (mm)	Qty	✓
1	425x383x50	2		11	490x208x18	1	
2	419x490x18	2		12	460x150x14	1	
3	1654x400x24	1		13	444x513x3	2	
4	425x373x18	1		14	469x342x3	1	
5	425x373x18	1		15	160x50x50	2	
6	494x373x18	1		16	160x50x50	2	
7	524x355x15	2		17	350x150x14	1	
8	1520x68x18	1		18	350x150x14	1	
9	1630x388x18	1		19	283x50x18	2	
10	1520x40x18	1		20	444x513x3	1	




- 2** **A** 030093 x24
- C** 230010 8x32 x8
- D** 210020 x2
- F** 030052 M4x22 x2
- K** 250012 3.5x15 x8
- M** 180096 x4



- 3** **B** 030110 x8
- J** 070017 30x30 x4





4




B 030110
x8

5


B 030110
x4



6




B 030110
x8





7

B 030110
x8



8

I 220043
x2



9

A 030093
x4


B 030110
x4

C 230010
8x32
x6

D 210020
x1

F 030052
M4x22
x1

L 250024
3.5x35
x2



10

E 030043
M4x10
x2

G 190002
x8

V 180080
x1

V1 090004
x1

V2 250012
3.5x15
x1

V3 250044
4x40
x1

