


ДАНИЯ

Тумба ТВ




 **TIMBERICA**

RU Инструкция по сборке

EN Assembly instruction

FI Koontaohje



1022
2



1004
22



1038
50




1028
35



1027
35




1006
24




1024
4




1040
12








3





4



5



6



7

